


BeatStep and Spark :

Sync the clock :

- Click on « Setup » in the upper left section of the windows, set « master » in Midi Clock Sync section, then set « Arturia BeatStep » in Midi Output section




- The «EXT SYNC» button on the BeatStep must be activate (blue highlighting)



- Spark is now synchronised with the BeatStep, so he is also synchronised with all the others machine you will connect to the BeatStep by CV or midi.

Mapping :


- Click on « Setup » in the upper left section of the windows, set « Arturia BeatStep » in Active Midi Inputs.



- Hold ctrl (cmd on mac) and select the virtual pad or knob you want to assign, then click on learn. Now play on the real knob or pad. A number must appear next to « midi note »

- Use the SparkLE GUI as interface for a better intergration

To activate the SparkLE GUI click on the onglet « PREFS » and choose « SparkLE » in interface section.



- !\ The settings button on the left of the BeatStep can't be midi mapped